

PROSPEC MF MIRROR FINISH WB **ENAMEL**

TDS01-340

DESCRIPTION A low odour industry first, high build waterbased Enamel finish coat that when applied over Prospec Holdout Sealer delivers a finish that is traditionally only achieved with Lacquer or Oil based enamels.

Prospec Mirror Finish Enamel is based on a novel polymer platform that conveys excellent early toughness and

chemical resistance to the coating's properties.

TYPICAL USES Exterior/interior surfaces including skirtings, window frames, doors, and residential cabinetry. Also provides an

excellent spray finish enamel for wet and service area broard-wall.

PERFORMANCE

Provides a durable, hard wearing surface where a Premium Door and Trim finish is required. Cleanable surface using detergent and moist microfibre cloth. Prospec Mirror Finish shows excellent blocking resistance and

chemical resistance and is non-yellowing.

LIMITATIONS Do not apply if the air and surface temperature during application is likely to fall below 10°C.

Interior: Spraying below 15°C, post spray heating is required. Above 15°C use air-fans to assist airflow and

accelerate drying.

Designed for spray application and can be touched up with microfibre roller.

TECHNICAL DATA Resin: Acrylic

Solvent: Water Appearance: White Colour: White and Pastel Primer: See over. **Durability: Excellent** Thining and Clean Up: Water

Pack Size: 4,10 VOC: <55g/litre Vol Solids: 32 percent

Touch Dry: 2 hours @15°C RH <70% Recoat Time: 2-4 Hours @20°C

Number of Coats: 2

Theoretical Coverage: 6 m²/litre/coat Wet Film Thickness: 160 microns Dry Film Thickness: 51 microns

AVAILABLE FINISHES

Sheen

@60°C

SPREAD RATE

Standard Application: 8 - m²/litre/coat Doors and Trim: 6 - m²/litre/coat

PRODUCT CODES 01-340



SURFACE PREPARATION Plasterboard-New Unpainted

All surfaces must be clean, dust free, free of dirt. loose material and any other surface contaminant and mould.

Plaster and all stoppings must be fully cured and sound. Any weak or powdery surfaces should be rectified before coating.

Avoid scuffing the drywall paper surface substrate as this will create a variation to the plaster that may create a textural difference. Ensure the plastering has been finished to a standard suitable for the specified level of

Inspect the substrate prior to applying any coating system to ensure no surface defects exists. Yellowed, sunlight exposed drywall paper needs to be sealed with TRUEPREP MULTIPURPOSE ALKYD PRIMER UNDERCOAT.

If required, apply appropriate flexible paintable sealant, to gaps between skirting boards, framing and scotia's and fill any minor defects using TRUEPREP STOP-IT FILLER. Allow to fully dry and sand smooth as required prior to priming.

Timber Dressed -New Unpainted PAINTING

All surface contaminants must be removed leaving the surface clean of dirt, grease and any other form of contamination. Ensure the timber is dry and has a moisture content of less than 15% before application.

Exterior: Any sharp edges on exterior surfaces should be arissed (rounded) prior to sanding to ensure adequate film builds can be achieved.

Sand all surfaces to be painted to an even flat smooth finish to provide a good key for the primer paint. Dust down and wipe with a damp cloth or tac rag to remove all dust. Take care to clean out corners. Allow to dry.

Inspect the substrate after applying first primer coat to ensure there is no surface defects that require repair prior to applying subsequent coat. Fill any minor defects using TRUEPREP STOP-IT Filler, or EPOTEC EPOXY 1:1 Fairing after primer coat is dry. Sand smooth and dust down prior to applying the next coat.

If required, apply appropriate flexible paintable sealant, to gaps between skirting boards, framing and scotia's.

Timber Dressed -New Unpainted STAINING

All surface contaminants must be removed leaving the surface clean of dirt, grease and any other form of contamination. Ensure the timber is dry and has a moisture content of less than 15% before application.

Inspect the substrate prior to applying any coating system to ensure there is no surface defects.

DEFECTS: Repair or fill as required, taking care to use a filler of similar tone to the timber, prior to applying first coat.

Sand all surfaces to be painted to an even flat smooth finish to provide a good key for the new paint system. Dust down and wipe with a damp cloth to remove all dust. Allow to dry.

MIXING INSTRUCTIONS Stir thoroughly before use and regularly during prolonged application.

APPLICATION Airless Spray

SPRAY

Airless Graco 395 or larger: Pressure 2500-2700 psi, max. tip size 208-308, 411-413. 100 Mesh Gun Filter

CLEAN UP

Water

APPLICATION NOTES Refer PS-C012 PROSPEC Operating guide HS MF Doors and Trim

This formulation uses the latest technology with low toxicity, ensuring environmental issues are not compromised. DO NOT POUR paint or wash down storm water or water courses. ALWAYS dispose of in accordance with local Government regulations. Soak up spills with absorbent material and dispose of properly. If spraying use suitable respiratory protection. Refer to the MATERIAL SAFETY DATA SHEET

ENVIRONMENTAL

COATING TECHNOLOGIES LIMITED

10 Andromeda Crescent, East Tamaki, Auckland 2013 Ph +64 9 837 0897 www.cotec.co.nz

THINNING Add up to 5% Cotec spray thinner if required on hot days.

Technical information given verbally or in writing is based on knowledge and research, given in good faith and believed to be reliable, but no guarantee of accuracy is made or implied. Since methods and conditions of use are beyond our control, all merchandise is sold and received subject to the condition that our liability whether express or implied for any defect in quality, or for any lack of fitness for the specified use thereof, is limited to the return of the purchase price if written claim is made within 14 days from the date of delivery. It is recommended that the user makes his or her own tests to determine the suitability of the product for his own requirements. Freedom from patent restrictions is not implied.